

## CARE & USE

### DRY ERASE PORCELAIN ENAMEL MARKER SURFACES

An initial cleaning of your MARKERBOARD should be performed to ensure that no residual film or abrasive residues are present to damage the surface.

#### PROPER USAGE:

1. **WRITE** on your board with specially formulated DRY ERASE MARKERS designed for that specific purpose. We recommend either EECOMARK® Dry Erase Markers or EECO Dry erase marker pens.
2. **ERASE** YOUR BOARD with a soft cloth or felt eraser of #2 quality or better.
3. **WASH** your board periodically to eliminate problems from built up dust, grease or airborne contaminants.

#### CLEANING & MAINTENANCE:

**SPRAY** your board with EcoClean® marker board cleaner or any liquid ammonia-added cleaner.

DO NOT use directly or indirectly any abrasives, polishing cleaner, streak-free cleaners, anti-fogging agents or vinegar-added cleaners.

**RINSE** with clear water and **DRY** your board with a soft towel.

A sponge and squeegee will work great, and are much easier for large boards. 100% Cotton towels or rags are a cheap solution.

REMEMBER that the writing surface is PORCELAIN and like GLASS it will chip and craze if subjected to improper handling. This surface is impervious to chemical attack, so if it is written on with permanent marker, crayon, pen, or etcetera DO NOT panic. These stains, and tape adhesive residue can be cleaned using the method above.

For stubborn residue, use a mild solvent or denatured alcohol. Gently work on your stain in a circular motion.

For permanent markings, write directly over-top of the permanent markings with a dry erase marker. Allow time to soak in & erase.

If you have a situation where none of these procedures have worked such as a scratched or cracked surface, just call our office at 330-673-4881.