



## PRO STEEL PORCELAIN ENAMEL MARKER BOARDS

### CARE & CLEANING

An initial cleaning of your MARKERBOARD should be performed to ensure no residual film or abrasive residues are present to damage the surface.

1. Erase your board with a soft cloth or felt eraser of #2 quality or better.
2. Write on your board with specially formulated dry erase markers designed for this specific purpose.
3. Wash your board periodically to eliminate problems from built up dust or other contaminants.

Wash your board with any liquid ammonia-added cleaner. Rinse with clear water and dry your board with a soft towel. A sponge and a squeegee will work great, and are much easier for large boards.

Remember that the writing surface is PORCELAIN. Like glass it will chip and craze if subjected to improper handling. Also, like glass, the surface is impervious to chemical attack, so do not panic if someone writes with permanent marker, crayon, pen, etc. These stains, and tape adhesive residue can be cleaned using the method above. For stubborn residue, use a mild solvent or a paste made from scouring powder and water. Gently work on your stain in a circular motion.